



Customer Help Sheet: Re-starting the unit

Introduction

From time to time it may be necessary to re-start a RIOT-S – for example if it has lost connection with the network.

Instructions

1. Press the time in the top right corner of the screen.

Inputs		Home	Back	12:23
Name	Reading	Status		
Fridge 1 Core	4.2	OK		
Fridge 1 Air	5.3	OK		
Fridge 2 Core	3.7	OK		
Fridge 2 Air	3.2	OK		
Freezer 1	-21.5	OK		
Freezer 2	-37.4	OK		
HACCP	26.2	OK		

The 'Setup' menu will be displayed.

NOTE: If you are not already logged on as a user then you will be prompted to do so. To re-start the RIOT-S you will need to log on as a user with a "service" access level.

2. Press the 'Service Menu' button.

Setup		Home	Back	12:23
Alm Templates	Logoff now			
Actions	Contacts / Users			
Schedules	Set Time			
Input List	Service Menu			
System Config	Sounds Menu			
Print Log	Touch Calibrate			

The 'Service' menu will be displayed.

3. Press the 'Battery' button.

Service		Home	Back	12:23
IT Settings	USB Backup			
TCPIP Status				
	PSTN Modem			
	System Alarm			
Battery	Raw Inputs			
S/W Version	AAW Config			

The 'Battery' parameters will be displayed.

Customer Help Sheet: Re-starting the unit

- Press the setting for the 'Kill Power' parameter.

Battery		Home Back 12:23
Parameter	Setting	Units
Supply	Present	
Vbat	5.2	V
Charge Time	00:00	Off
Kill Power		
Run On Time	00:00	sec
Touch On Time	00:00	sec

An 'Edit' screen will be displayed showing the current setting for the selected parameter.

- Press the 'Shutdown' option, then press 'Ent'.

Edit		Home Back 12:23
Kill Power		
<	Shutdown	>
Abort	Shutdown	Low power
Can		Ent

The RIOT-S will be turned off.

- Wait for the RIOT-S to turn itself back on.

Inputs		Home Back 12:23
Name	Reading	Status
Fridge 1 Core	0.0	
Fridge 1 Air	0.0	
Fridge 2 Core	0.0	
Fridge 2 Air	0.0	
Freezer 1	0.0	
Freezer 2	0.0	
HACCP	0.0	

Provided that the RIOT-S has mains power, it will turn itself back on after 5 – 10 seconds and display the 'Home' screen.

If the RIOT-S does not have mains power, then it will turn itself back on when it is next connected to mains power.

NOTE: After the RIOT-S has turned itself back on it may take several minutes for all the readings and statuses to be updated/shown.

Inputs		Home Back 12:23
Name	Reading	Status
Fridge 1 Core	4.2	OK
Fridge 1 Air	5.3	OK
Fridge 2 Core	3.7	OK
Fridge 2 Air	3.2	OK
Freezer 1	-21.5	OK
Freezer 2	-37.4	OK
HACCP	26.2	OK